




Single Ended Recuperative Burners

Models SER450, SER600 & SER750

Version 3



COPYRIGHT

Copyright 2004 by Eclipse, Inc. All rights reserved worldwide. This publication is protected by federal regulation and shall not be copied, distributed, transmitted, transcribed or translated into any human or computer language, in any form or by any means, to any third parties, without the express written consent of Eclipse, Inc., Rockford, Illinois, U.S.A.

DISCLAIMER NOTICE

We reserve the right to change the construction and/or configuration of our products at any time without being obliged to adjust earlier supplies accordingly.

The material in this manual is believed adequate for the intended use of the product. If the product, or its individual modules or procedures, are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained. Eclipse, Inc. warrants that the material itself does not infringe any United States patents. No further warranty is expressed or implied.

We have made every effort to make this manual as accurate and complete as possible. Should you find errors or omissions, please bring them to our attention so that we may correct them. In this way we hope to improve our product documentation for the benefit of our customers. Please send your corrections and comments to our Documentation Manager.

LIABILITY AND WARRANTY

It must be understood that Eclipse's liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the furnishing of such replacement parts and Eclipse, Inc. will not be liable for any other injury, loss, damage or expenses, whether direct or consequential, including but not limited to loss of use, income or damage to material arising in connection with the sale, installation, use of, inability to use or the repair or replacement of Eclipse's products.

Any operation expressly prohibited in this Guide, any adjustment, or assembly procedures not recommended or authorized in these instructions shall void the warranty.



About this manual

AUDIENCE

This manual has been written for people who are already familiar with all aspects of a nozzle-mix burner and its add-on components, also referred to as “the burner system.”

These aspects are:

- installation
- use
- maintenance.

The audience is expected to have had experience with this kind of equipment.

PURPOSE

The purpose of this manual is to provide information to assist in the installation of Eclipse products in a safe, effective, and trouble-free combustion.

SER DOCUMENTS

Installation Guide No. 325

- This document

SER Data Sheets, Series 325

- Available for individual SER models
- Required to complete design, selection & installation

Design Guide No. 325

- Used with Data Sheet to design burner system

SER Price List No. 325 & 325-I

- Used to order burners

RELATED DOCUMENTS

- EFE 825 (Combustion Engineering Guide)
- Eclipse Bulletins and Info Guides: 684, 710, 732, 742, 756, 760, 930

DOCUMENT CONVENTIONS

There are several special symbols in this document. You must know their meaning and importance.

The explanation of these symbols follows below. Please read it thoroughly.



Danger:

Indicates hazards or unsafe practices which **WILL result in severe personal injury or even death. Only qualified and well trained personnel are allowed to carry out these instructions or procedures.**

Act with great care and follow the instructions.



Warning:

Indicates hazards or unsafe practices which could result in severe personal injury or damage.

Act with great care and follow the instructions.



Caution:

Indicates hazards or unsafe practices which could result in damage to the machine or minor personal injury, Act carefully.



Note:

Indicates an important part of the text. Read thoroughly.

HOW TO GET HELP

If you need help, contact your local Eclipse Combustion representative. You can also contact Eclipse Combustion at any of the addresses listed on the back of this document.



Table of Contents

	About this manual	3
	Table of Contents	5
1	Introduction	6
	Product description	6
2	Safety	7
	Introduction	7
	Safety	7
	Capabilities	8
	Operator Training	8
	Replacement Parts	8
3	Installation	9
	Introduction	9
	Handling and Storage	9
	Approvals of Components	9
	Pre-installation Checklist	10
	Furnace Wall Preparation	11
	Burner Disassembly	11
	Mounting Flange Installation	12
	Exhaust Housing Installation	12
	Burner Installation	13
	Flame Sensor Installation	14
	Piping	14
	Valves	15
	Check List After Installation	16
	Prepare For Adjustment	16
4	Adjustment, Start & Stop	17
	Introduction	17
	Adjustment Procedure	17
	Step 1: Reset the system	17
	Step 2: Set high fire air	18
	Step 3: Set low fire air	18
	Step 4: Varyify the air settings	18
	Step 5: Ignite the burner(s)	19
	Step 6: Set high fire gas	20
	Step 7: Set low fire	20
5	Maintenance & Troubleshooting	21
	Appendix	26
	Illustrated Parts List	28

Introduction

1


PRODUCT DESCRIPTION

Eclipse Model SER Version 3 Single Ended Recuperative burners incorporate the components of a tube firing burner system in a compact package. The SER burner is a nozzle mixing burner and recuperator coaxially mounted inside a single-ended radiant tube. Combustion air entering the SER burner is preheated in the recuperative section by exhaust gases providing higher efficiencies than stand alone burners. SER V3 burners are available in three diameters (4-1/2", 6", 7-1/2"). Radiant tube length is tailored to the application. SER burners have the added features of internal flue gas recirculation resulting in lower NO_x emissions and ceramic inner tube sections allowing higher flux rates and promoting longer tube life.

Features:

- Direct spark ignition
- Reliable burner operation
- Uniform tube temperature
- Tube life comparable to conventional radiant tubes
- Simple burner adjustment
- Multi-fuel capability

The Single Ended Recuperative Burner





2

INTRODUCTION

SAFETY

This section is provided as a guide for the safe operation of the SER burner system. All involved personnel should read this section carefully before operating this system.



Danger:

The SER burners, described herein, are designed to mix fuel with air and burn the resulting mixture. All fuel burning devices are capable of producing fires and explosions if improperly applied, installed, adjusted, controlled, or maintained.

Do not bypass any safety feature; fire or explosion could result.

Never try to light a burner if it shows signs of damage or malfunction.



Warning:

The burner might have HOT surfaces. Always wear protective clothing when approaching the burner.



Note:

This manual provides information in the use of these burners for their specific design purpose. Do not deviate from any instructions or application limits described herein without written advice from Eclipse Combustion.

Read the entire this manual and all related documents before attempting to start this system. If you do not understand any part of the information contained in this manual, contact your local Eclipse representative or Eclipse Combustion before continuing.

CAPABILITIES

Only qualified personnel, with good mechanical aptitude and experience on combustion equipment, should adjust, maintain, or troubleshoot any mechanical or electrical part of this system.

OPERATOR TRAINING

The best safety precaution is an alert and trained operator. Train new operators thoroughly and have them demonstrate an adequate understanding of the equipment and its operation. A regular retraining schedule should be administered to ensure operators maintain a high degree of proficiency.

REPLACEMENT PARTS

Order replacement parts from Eclipse Combustion only. All Eclipse Combustion approved, customer supplied valves or switches should carry UL, FM, CSA, CGA, and/or CE approval, where applicable.



Installation

3

INTRODUCTION

In this section you will find information and instructions needed to install the burner and system components.

HANDLING AND STORAGE

Handling

Inspect the system, make sure the components are clean and free of damage.

Use the appropriate support and handling equipment when lifting the burner.

Protect all components on the system from weather, damage, dirt and moisture.

Protect the system and its components from excessive temperatures and humidity.

Storage

When storing the system for an extended period Eclipse recommends placing it in a cool, clean, dry room.

Keep all the system components stored in their original packaging until ready to install.

POSITION OF COMPONENTS

The position and amount of components are determined by the kind of control method chosen. All the control methods can be found in Design Guide 325, Chapter 3 “System Design”. Use the schematics to build your system.

APPROVALS OF COMPONENTS

Limit controls and safety equipment

All limit controls and safety equipment must comply with all applicable local codes and/or standards, which may include:

- NFPA Standard 86
- NFPA Standard 86C
- UL
- FM
- CGA
- EN 746-2

Electrical wiring

All electrical wiring must comply with all applicable local codes

and/or standards, which may include:

- NFPA Standard 70
- ANSI-C11981
- EN 746-2

Gas piping

All gas piping must comply with all applicable local codes and/or standards, which may include:

- NFPA Standard 54
- ANSI Z223
- EN 746-2

Where to get the standards:

NFPA:

National Fire Protection Agency
Batterymarch Park
Quincy, MA 02269
www.nfpa.org

ANSI:

American National Standard Institute
1430 Broadway
New York, NY 10018
www.ansi.org

UL:

Underwriters Labs
333 Pfingsten Road
Northbrook, IL 60062
www.ul.com

FM:

Factory Mutual System
1151 Boston-Providence Turnpike
P.O. Box 9102
Norwood, MA 02062
www.factorymutual.com

CGA:


Canadian Gas Association
55 Scarsdale Road
Toronto, Ontario
Canada M3B 2R3
www.cga.ca

EN:


Comité Européen de Normalisation
Strassartstraat 36
B-1050 Brussels

PRE-INSTALLATION CHECKLIST

DIMENSIONAL CHECK



FURNACE WALL PREPARATION



Air Supply

Provide an opening in the burner room of at least one square inch per 3000 BTU/hr (5 cm² per 1 kW) to supply the burner intake with fresh, outdoor, combustion air.

If there are corrosive fumes or materials in the surrounding air, find an uncontaminated source to supply air to the burner.

Exhaust

Do not allow exhaust gases to accumulate in the work area. Provide a means for exhausting these gases from the building.

Access

Install the burners so they may be easily accessed for inspection and maintenance.

Environment

Be sure the burner operating environment matches the original operating specifications. Check the following items:

- voltage, frequency, and stability of electrical power
- fuel type and fuel supply pressure
- adequate fresh, clean, combustion air
- humidity, altitude, and temperature of the supply air
- presence of damaging corrosive gases in the air
- prevent direct exposure to water.

Confirm Burner/Furnace Compatibility

Prior to the installation of the SER burner assembly, it is important to check that the unit supplied will fit the furnace correctly. If vertically mounted, measure the distance from the casing to the hearth.

If the burner is horizontally mounted, measure the distance from the casing to the far side brickwork.

This dimension should agree with the Hot Face to Hot Face dimension provided on Price List 325 page 2. If the dimension is correct, the end of the outer tube will be at least 3" (76.2 mm) from the hearth brickwork when mounted vertically or from the far wall if mounted horizontally. This clearance is required to allow the metallic outer tube to expand freely during operation.

Make sure the furnace wall is capable of supporting the weight of the burner to be installed. If necessary, reinforce the mounting area. A round opening less than .5" (12.7mm) larger than the OD of the radiant tube must be provided in the casing of the furnace. A larger hole through the refractory is acceptable and should be filled with insulation. To verify nozzle position within the furnace wall, measure from the mounting face of the exhaust housing to the or the combustor transition point. Compare to furnace wall thickness plus mounting flange. These dimensions should be within 1" (25mm).


BURNER DISASSEMBLY



Rear Cover
Nozzle Assembly

The burner must be disassembled to install in the furnace:


- Remove the rear cover (4 cap screws, M8) and slide the rear cover nozzle assembly from the burner.
- Remove the air inlet housing (4 bolts, M12) and slide the combustor assembly through the exhaust housing.
- Remove the exhaust housing (4 bolts, M12) from the extension mounting flange (if applicable).



Note:

Outer tube is typically shipped separately.

MOUNTING FLANGE INSTALLATION




The extension mounting flange, if utilized, must be welded to the casing of the furnace. In order to insure proper alignment of the mounting flange:

- Center the mounting flange on the opening in the furnace wall.
- Insure the face of the mounting flange is perpendicular to the centerline of the opening.
- Rotate the mounting flange such that it is square with respect to the vertical centerline of the clearance hole in the furnace.
- Weld mounting flange to the furnace casing with a continuous full penetration weld.

EXHAUST HOUSING INSTALLATION

If an extension mounting flange is not used, 4 studs must be provided on the furnace wall to mate with the exhaust housing flange (see page 3 of the Data Sheet for the burner you are installing). The studs should be installed similar to the extension mounting flange: centered, perpendicular and square to the opening in the furnace wall.



Provide Outer Tube Support

SER burner outer tubes must be supported if their effective length is longer than 36" (915mm). There are a variety of means for providing support:

- 1 Provide a simple support for the tube from the furnace hearth
- 2 Cantilever a simple support from the opposite furnace wall
- 3 Provide an opening in the opposite furnace wall to support an outer tube equipped with a mounting stub.




Caution:

Call your Eclipse sales representative to review



Note:



For vertical applications, contact Eclipse Sales Representative.



■ = LOW FRICTION Silicon Carbide Brick

Once the tube support has been provided, the outer tube can be installed.

BURNER INSTALLATION



The following instructions apply to burners with metallic outer tubes. For burners with ceramic outer tubes reference 325IG Supplement

1. Place gasket over outer tube.
2. Slide outer tube through extension mounting flange (if applicable) and prepared hole in the furnace.
3. Place gasket against outer tube. Use adhesive spray to hold gaskets in place during horizontal installation. Photo 1
4. Assemble exhaust housing to the extension mounting flange (if applicable) using nuts and bolts or to the studs (if applicable) using nuts. Photo 2



Note:

Use anti-sieze compound on all bolts when assembling.




Note:

Outer tube may require centering to assembly. Nuts and bolts should be torqued to 15-20 ft-lbs cold and retorqued at operating temperature and after 100 hours of operation. Position housing so exhaust is orientated correctly for application.


5. Place gasket against exhaust housing. Use adhesive spray in horizontal applications Photo 2.




Combustor Assembly Gasket




Gasket



Air Inlet Housing



Rear Cover Nozzle Assembly



8

Rear Cover Gas Inlet

6. Install inner metallic tube or ceramic sections. Starting with the end section, add the inner tube section(s) one into the other and push them to the bottom of the outer tube. Make sure the inner tube/sections are bottomed in the outer tube. Photo 3

7. Install combustor assembly through exhaust housing into outer tube. Photo 4

8. Place gasket against combustor assembly. Photo 5

9. Assemble air inlet housing to exhaust housing using bolts and nuts. Position air inlet so it is aligned with air manifold. Photo 6



Note:

Combustor assembly may require centering to assembly. Nuts and bolts should be torqued to 15-20 ft-lbs cold and retorqued at operating temperature and after 100 hours of operation. Position housing so air inlet is orientated to align with the air manifold piping.


10. Slide the rear cover nozzle assembly through the air inlet housing and into the combustor assembly. Photo 7

11. Assemble the cover to the inlet air housing using cap screws. Torque 5 ft-lbs. Position cover so gas inlet is aligned with gas manifold piping. Photo 8




Completed Burner Assembly

FLAME SENSOR INSTALLATION



UV scanner
location



Flame sensor;
90° U.V. scanner

Piping

U.V. Flame sensing:

1. Install the flame sensor into the opening in the rear cover.
2. Make sure that the U.V. scanner is connected to the electrical circuit of that burner.



Danger:

Connecting the U.V. scanner of a burner to the electrical circuit of a different burner can cause fires and explosions.

For detailed information on how to install and connect a UV scanner, refer to:

- straight UV scanner; Bulletin / Info Guide 854
- 90° UV scanner; Bulletin / Info Guide 852
- self-check UV scanner; Bulletin / Info Guide 856
- solid state UV/IR scanner; Bulletin / Info Guide 855.

Layout

Install the piping as shown in the schematics. Refer to Chapter 3 of the SER Design Guide No. 325.

Support the piping

Use brackets or hangers to support the gas piping. If you have questions, consult your local gas company.

Straight run of pipe before a metering orifice



Note:

There must be a run of pipe with a straight length of at least 10 pipe diameters before the burner metering orifice. Failure to provide this length will result in inaccurate pressure readings.

Pipe connections

1. Install a pipe union in the gas line to the burner. This simplifies removal of the burner.
2. The use of flexible pipe nipples in the gas line to the burner is optional. Flexible nipples can absorb stress due to heat expansion and slight misalignment.



Note:

Flexible pipe nipples will cause inaccurate metering orifice readings if installed in the burner inlet and may cause higher pressure drops than equivalent standard pipe. Consider this when you size the gas lines.






Avoid large pressure drops



Note:

Pressure drop in the piping is a critical parameter. Make sure that the size of all the piping is large enough to prevent excessive pressure losses.

Valves



Valve orientation

Install all the valves in such a way that the arrow (if present) on the valve body points in the direction of flow.

Gas cocks

Make sure that the handle of a gas cock is at a right angle to the valve body when the valve is in the closed position. This is an important position indicator.

Gas balancing valves

A gas balancing valve is typically the same as a manual butterfly valve. For more information, refer to the section below.

Manual butterfly valves

1. Install manual butterfly valves in accordance with Bulletin/Info Guide 720.
2. Install manual butterfly valves in the gas line to the burner (optional).



Note:

It is recommended that there is a run of pipe with a length of at least 10 pipe diameters between any flow altering device and the metering orifice on the burner.

Automatic butterfly valve

An automatic butterfly is driven by an actuator (actuator and mounting bracket not illustrated).

1. Install the control valve in accordance with Bulletin/Info Guide 720.

Ratio regulator

1. Connect an impulse line to the ratio regulator and to the air supply line.
2. Install the ratio regulator in accordance with Bulletin/Info Guide 742.



Note:

The inlet gas pressure to the ratio regulator must be higher than the impulse line pressure at high fire condition.

CRS valve

Install the CRS valve in accordance with Bulletin/Info Guide 744.

CHECKLIST AFTER INSTALLATION

PREPARE FOR ADJUSTMENT

To verify proper system installation, do the following:

1. Make sure that there are no leaks in the gas lines and the air lines.
2. Make sure all the components of the flame monitoring control system are properly installed. This includes verifying that all switches are installed in correct locations and all wiring, pressure and impulse lines are properly connected.
3. Make sure components of spark ignition system are installed and functioning properly.
4. Make sure that the blower rotates in the correct direction. If incorrect, have a qualified electrician rewire the blower to reverse its rotation.
5. Make sure all valves are installed in proper location and correctly oriented relative to the gas or air flow direction.

After installation of the burner system components is complete, the following steps should be followed in order to prepare for adjustment:

1. Set the air pressure switches.
2. Close all the burner gas cocks.
3. Try to light a burner before the purge and other timers have finished their cycles. Make sure that the flame monitoring system indicates a flame failure.
4. Trip out pressure switches and other limit interlocks. Make sure that the main gas valve train closes.



Danger:

If simulated limits or simulated flame failures do not shut down the fuel system within the required failure response time, immediately correct the problem before proceeding.

**THIS PAGE INTENTIONALLY
LEFT BLANK.**

Adjustment, Start & Stop

4

INTRODUCTION

In this chapter, you will find instructions on how to adjust, start, and stop the burner system. Become familiar with burner control methods before attempting to make adjustments. Read all of this chapter before starting the system.



Danger:

The SER burners described herein are designed to mix fuel with air and burn the resulting mixture. All fuel burning devices are capable of producing fires and explosions if improperly applied, installed, adjusted, controlled, or maintained.

Do not bypass any safety feature; fire or explosion could result.


Never try to light a burner if it shows signs of damage or malfunction.

ADJUSTMENT PROCEDURE

If you are adjusting the system for the first time, follow these steps.

1. Reset the system
2. Set high fire air
3. Set low fire air
4. Verify the air settings
5. Ignite the burner(s)
6. Set high fire gas
7. Set low fire gas

Step 1: Reset the system



1. Close the automatic gas valves and the gas cocks.
2. Fully open the manual air butterfly valve at each burner.
3. Drive all the automatic zone air control valves to high fire.

Note:




The automatic zone air control valve may require adjustment so that it is fully open. The automatic zone air control valve can be either a butterfly valve or a CRS valve.

4. Start the blower.

Step 1: Reset system (continued)

Step 2: Set high fire air



Step 3: Set low fire air

Step 4: Verify the air settings.



Caution:

Make sure that the blower rotates in the correct direction. If incorrect, have a qualified electrician rewire the blower to reverse the rotation.

1. With gas cocks remaining closed and the system at high fire, use the air curves from the appropriate SER Data Sheet to find the differential air pressure needed at high fire. This is now the target value for high fire.
2. Set high fire air.



Note:

The pressure tap is in the open position when the screw inside the tap is unscrewed approximately 1/2 turn. Do not remove screw.

Single Burner System:

- a. Adjust the manual butterfly valve until the high-fire differential air pressure across the air orifice (taps A and C) is at the target value.

Multiple Burner System:

- a. Adjust the zone air manual butterfly valve to achieve the target differential air pressure between taps A and C for the first burner.
- b. Measure and note the differential air pressure across the remaining burners in the zone.
- c. If all the measured differential pressures are within 0.3" w.c. (0.75 mbar) of each other, proceed to the next section. If the variation is greater than 0.3" w.c. (0.75 mbar) it will be necessary to adjust the manual air butterfly valve at each burner to improve balance.



Note:



Be sure to tighten pressure tap screw clockwise to the closed position after pressure measurements have been taken.

3. Repeat 2. for other zones (if any).

1. Set the system to low fire by adjusting the automatic zone air control valve until the low-fire static air pressure at tap A is 0.4" w.c. (1.0 mbar). This is the initial setting only. Further adjustment may be necessary.
2. Repeat Step 2 for other zones (if any).

Cycle the system between low and high fire several times, verifying that all settings remain the same.

Step 5: Ignite the burner(s)
(Manual ignition steps)



Step 5: Ignite the burner(s)
(Automatic ignition steps)



Note:

Manual ignition is the recommended start procedure for cold start-up.

1. Drive the zone air automatic control valve to low fire.
2. Make sure the combustion air blower is running.
3. Set the manual gas butterfly valve at each burner to 50% open.
4. Set the adjusting screw on the ratio regulator six full (360°) turns clockwise from the top (initial setting).
5. Open zone manual gas cock.
6. Start the ignition transformer.



Danger:

To avoid the risk of electrical shock, do not touch the ignition plug or the ignition wire when the ignition is on.

7. Open burner manual gas cock. Burner should ignite.
8. If burner does not ignite in 3 seconds, close gas cock.
9. Wait at least 30 seconds for purge and repeat Step 7.
10. If the burner fails to light after the second attempt, adjust ratio regulator clockwise one turn and repeat Step 7.
11. Terminate ignition transformer.
12. Repeat steps 6 through 11 for all burners in the zone.




Warning:


These procedures are written with the assumption that each burner is connected to a flame monitoring control system that is installed and operating. A proper purge cycle must be part of the system and purge timing should not be bypassed.

1. Drive the zone air automatic control valve to low fire.
2. Make sure the combustion air blower is running.
3. Set the manual gas butterfly valve at each burner to 50% open.
4. Set the adjusting screw on the ratio regulator six full (360°) turns clockwise from the top (initial setting).
5. Open zone manual gas cock.
6. Open manual gas cock at each burner.
7. Initiate the ignition sequence through the flame monitoring system (check for flame, initiate spark, open gas solenoid, trial time, check for flame).
8. Check that all the burners in the zone have ignited.
9. If the burner fails to light after repeated attempts, adjust ratio regulator clockwise one turn and repeat Step 7.

Step 6: Set high fire gas



Step 7: Set low fire gas



10. If a gas solenoid valve is fitted at each burner, repeat Step 7 for each burner in the zone.

1. With the burners lit, drive the zone air automatic control valve to high fire.
2. Check the gas pressure at the inlet to the zone ratio regulator. This should be at least 5" w.c. (12.5 mbar) higher than the loading line pressure. It should not exceed the maximum pressure rating of the ratio regulator.



Warning:

Insufficient gas inlet pressure may cause the ratio-regulator to remain fully open as the burner system turns down from high fire, causing excess fuel operation and the possible accumulation of unburned fuel in the chamber. In extreme cases, this may cause explosions or fires.

3. Use the gas curve from the appropriate SER Data Sheet for the gas being used to find the differential gas pressure needed at high fire. This is the target value for high fire.
4. Adjust the high fire gas pressure by adjusting the manual gas BV until the ΔP across the gas orifice between tap B and tap D is at the target value.



Note:

Be sure to tighten pressure tap screw clockwise to the closed position after pressure measurements have been taken.

5. Repeat Step 3 for the other burners in the zone.
6. Bring furnace temperature to operational level.
7. Verify high fire air pressure ΔP (Step 2a page 18). Adjust zone manual air butterfly valves if necessary to obtain correct levels or manual butterfly valves to restore balance between burners.
8. Fine adjust the gas butterfly valves to obtain 3% to 5% O₂ in the exhaust gas.
9. Repeat Steps 7 & 8 for other burners in the zone.

1. Drive the system to low fire while at operational furnace temperatures.
2. Adjust the ratio-regulator to achieve 12% to 15% O₂ in the exhaust gases. Turning counter clockwise lowers gas flow and increases O₂ reading.



Note:

The main objective of setting low fire is to provide a clean stable flame with a reliable flame signal that will not cause the furnace temperature to overshoot. For tubes < 60" in length, slightly higher O₂ levels are recommended.



Maintenance & Troubleshooting

5

INTRODUCTION

This chapter is divided into two sections:

- Maintenance procedures
- Troubleshooting guide

Preventive maintenance is the key to a reliable, safe and efficient system. The core of any preventive maintenance system is a list of periodic tasks.

MAINTENANCE



Note:

These are guidelines only. The customer should make the final determination on maintenance intervals and tasks to be performed while considering the working environment.

Monthly Checklist

1. Inspect the flame sensing devices for good condition and cleanliness.
2. Check for proper air/gas pressures (Refer to the SER Data Sheets, Series 325).
3. Test all the system alarms for proper response signals.
4. Check and clean igniter electrodes.
5. Check the air control valve for smooth, trouble free operation and adjustment.
6. Check for the proper operation of ventilating equipment.
7. Test the interlock sequence on all safety equipment. Manually force each interlock to intentionally fail while at the same time noting if related equipment closes or stops as specified by the manufacturer. Test the flame safeguard by manually shutting off the gas to the burner.
8. Test the manual gas shut off cocks for proper operation.
9. Clean and/or replace the combustion air blower filter.
10. Inspect and clean the combustion air blower rotor.

Yearly Checklist



1. Leak test the safety shut-off valves for tightness of closure.
2. Test the pressure switch settings by checking the switch movements against pressure settings and comparing these with the actual impulse pressure.
3. Visually check igniter cable and connectors.
4. Inspect impulse line for leaks.
5. Be sure the following components are not damaged or excessively dirty:
 - the burner nozzle.
 - the igniter.
 - the flame sensors.
 - the inner and outer tubes
6. Rotate inner and outer tubes 180°.



Note

Burner nozzle and inner and outer tubes can be inspected by following the steps outlined on page 13 in reverse order.

TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE	SOLUTION
<p>Start-up sequence runs but burner does not light.</p>  <p>12-28 mm (5-1.1 inches) Position of Igniter</p>  <p>30-46 mm (1.2-1.8 inches) Position of Flame Rod</p>	<p>No ignition:</p> <ul style="list-style-type: none"> There is no power to the ignition transformer. 	<p>Restore the power to the ignition transformer.</p>
	<p>No ignition:</p> <ul style="list-style-type: none"> Open circuit between the ignition transformer and the igniter. 	<p>Repair or replace the wiring to the igniter.</p>
	<p>No ignition:</p> <ul style="list-style-type: none"> The igniter needs cleaning. 	<p>Clean the igniter.</p>
	<p>No ignition:</p> <ul style="list-style-type: none"> The igniter is not correctly grounded to the burner. 	<p>Clean the threads on the igniter and the burner. NOTE: Do not apply grease to the threads on the igniter.</p>
	<p>No ignition:</p> <ul style="list-style-type: none"> Igniter insulator is broken. Igniter is grounding out. 	<p>Inspect the igniter. Replace if broken.</p>
	<p>No ignition</p> <ul style="list-style-type: none"> Igniter in wrong position 	<p>Check that the igniter extends the proper distance beyond the nozzle face. See illustration at left.</p>
	<p>Not enough gas/too much gas:</p> <ul style="list-style-type: none"> The gas pressure going into the ratio regulator is too low or high. 	<p>Check the gas pressure out of the main gas regulator and adjust if necessary.</p>
	<p>Not enough gas:</p> <ul style="list-style-type: none"> The impulse line to the ratio regulator is leaking. 	<p>Repair any leaks.</p>
	<p>Not enough gas:</p> <ul style="list-style-type: none"> Start gas solenoid valve does not open. 	<p>Check the solenoid valve coil for proper operation. Replace it if necessary.</p>
	<p>Not enough gas:</p> <ul style="list-style-type: none"> Gas valve does not open. 	<p>Check the wiring to the automatic gas shut-off valve. Check the output from the flame safeguard. Open manual gas cock.</p>
	<p>Not enough gas:</p> <ul style="list-style-type: none"> Air in the gas line 	<p>Repeat the start attempt several times to purge air from gas line.</p>
	<p>No flame signal:</p> <ul style="list-style-type: none"> Dirty UV scanner lens The flame rod is improperly positioned 	<p>Inspect and clean sensor Replace if necessary Check that the flame rod extends the proper distance beyond the nozzle face. See illustration at left.</p>

PROBLEM	POSSIBLE CAUSE	SOLUTION
Start-up sequence runs but burner does not light. <i>(continued)</i>	Too much gas: <ul style="list-style-type: none"> Improper component piping sequence . 	Make sure solenoid valve is down stream of ratio regulator
	Too much gas: <ul style="list-style-type: none"> Gas BV too far open (high fire) Ratio regulator adjustment (low fire) 	Check for proper setting. Check for proper setting.
The low fire flame is weak or unstable.	<ul style="list-style-type: none"> Not enough gas flowing to the burner. 	Adjust the ratio regulator.
	<ul style="list-style-type: none"> Not enough air. 	Adjust the air control valve to increase low fire air flow.
The burner goes out when it cycles to high fire.	<ul style="list-style-type: none"> Insufficient air (flame too rich) 	Check start-up settings Check air filter, clean or replace if required
	<ul style="list-style-type: none"> Insufficient pressure into ratio regulator. 	Adjust press. settings on main gas regulator or change spring.
	<ul style="list-style-type: none"> Main gas adjustable valve not open enough. 	Adjust the main gas adjustable valve.
	<ul style="list-style-type: none"> Marginal air pressure switch setting. 	Adjust air pressure switch setting.
	<ul style="list-style-type: none"> Gas press. switch set incorrectly. 	Adjust switch setting.
The burner is erratic and does not respond to adjustment.	Internal damage to the burner: <ul style="list-style-type: none"> Some parts inside the burner are loose, dirty, or burned out. 	Contact your Eclipse representative or Eclipse Combustion for further information.
	<ul style="list-style-type: none"> Flame signal weak. 	Check the condition of the flame monitoring device.
The burner is unstable or produces soot, smoke, or excessive carbon monoxide.	<ul style="list-style-type: none"> The air/gas ratio is out of adjustment. 	Measure all the gas pressures and air pressures. Compare these pressures to the initial start-up settings and adjust them where necessary.
	<ul style="list-style-type: none"> Bleed fitting (if used) is dirty. 	Clean fitting.
The burner cannot achieve full capacity.	<ul style="list-style-type: none"> Air filter is blocked. 	Clean or replace the air filter.
	<ul style="list-style-type: none"> Gas pressure going into the ratio regulator is too low. 	Adjust the gas pressure.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The burner cannot achieve full capacity. (Continued)	<ul style="list-style-type: none"> Loading line pressure too low. 	Open the zone air control valve to increase the air volume and pressure. Recheck all burner settings.
	<ul style="list-style-type: none"> Adjusting valve has closed. 	Open the valve to previous setting and check the input and flue gas settings to verify proper operations.
	<ul style="list-style-type: none"> Blower is wired backwards. 	A blower wired to turn backwards will produce approximately 60% of its rated capacity. Check the rotation of the blower impeller. If spinning backwards, have a qualified electrician reverse the wiring.
	<ul style="list-style-type: none"> Poor piping practices 	Contact the factory.
Cannot initiate a start sequence.	<ul style="list-style-type: none"> Air pressure switch has not made contact. 	Check air pressure switch adjustment. Check air filter. Check blower rotation. Check outlet pressure from blower.
	<ul style="list-style-type: none"> Purge cycle not completed. 	Check flame monitoring control system or purge timer.
	<ul style="list-style-type: none"> High gas pressure switch has activated. Low gas pressure switch has activated. 	Check incoming gas pressure. Adjust gas pressure if necessary. Check pressure switch setting and operation.
	<ul style="list-style-type: none"> Malfunction of the flame safeguard system (e.g., shorted-out flame sensor or electrical noise in the sensor line). No power to the control unit. Main power is off. 	Have a qualified electrician troubleshoot and correct the problem. Be sure the main power to the system is switched to the “on” position.



Appendix

CONVERSION FACTORS

Metric to English.

From	To	Multiply By
cubic meter (m ³)	cubic foot (ft ³)	35.31
cubic meter/hour (m ³ /h)	cubic foot/hour (cfh)	35.31
degrees Celsius (°C)	degrees Fahrenheit (°F)	(°C × 1.8) + 32
kilogram (kg)	pound (lb)	2.205
kilowatt (kW)	BTU/hr	3414
meter (m)	foot (ft)	3.28
millibar (mbar)	inches water column ("w.c.)	0.401
millibar (mbar)	pounds/sq in (psi)	14.5 × 10 ⁻³
millimeter (mm)	inch (in)	3.94 × 10 ⁻²
MJ/m ³ (normal)	BTU/ft ³ (standard)	2.491 × 10 ⁻²

Metric to Metric.










kiloPascals (kPa)	millibar (mbar)	10
meter (m)	millimeter (mm)	1000
millibar (mbar)	kiloPascals (kPa)	0.1
millimeter (mm)	meter (m)	0.001

English to Metric.

From	To	Multiply By
BTU/hr	kilowatt (kW)	0.293 × 10 ⁻³
cubic foot (ft ³)	cubic meter (m ³)	2.832 × 10 ⁻²
degrees Fahrenheit (°F)	degrees Celsius (°C)	(°F – 32) ÷ 1.8
foot (ft)	meter (m)	0.3048
inches (in)	millimeter (mm)	25.4
inches water column ("wc)	millibar (mbar)	2.49
pound (lb)	kilogram (kg)	0.454
pounds/sq in (psi)	millibar (mbar)	68.95
BTU/ft ³ (standard)	MJ/m ³ (normal)	40.14

KEY TO SYSTEM SCHEMATICS

These are the symbols used in the schematics.

Symbol	Appearance	Name	Remarks	Bulletin/ Info Guide
		SER		
		Main Gas Shutoff Valve Train	Eclipse Combustion, Inc. strongly endorses NFPA as a minimum	756
		Gas Cock	Gas cocks are used to manually shut off the gas supply on both sides of the main gas shut-off valve train.	710
		Solenoid Valve (normally closed)	Solenoid valves are used to automatically shut off the gas supply on a bypass gas system or on small capacity burners.	760
		Pressure Regulator	A pressure regulator reduces gas pressure to a stable, usable pressure.	684
		Ratio Regulator	A ratio regulator is used to control the air/gas ratio. The ratio regulator is a sealed unit that adjusts the gas flow in ratio with the air flow. To do this, it measures the air pressure with a pressure sensing line, the impulse line. This impulse line is connected between the top of the ratio regulator and the air supply line.	742
		Automatic Zone Air Control Valve	Adjusts air flow to the burner based on control system requirements.	720
		CRS valve	A CRS valve is used in a high/low time-proportional control system to quickly open and close the air supply.	744

Illustrated Parts List


Pos. No.	Qty.	Description	Eclipse Part No.		
			SER450v3.0	SER600v3.0	SER750v3.0
1	8	Nut, lock, M12, Zinc Plated	21768	21518	21518
2	1	Optional Mounting Flange	10011763-x ⁽³⁾	100666-x ⁽³⁾	100667-x ⁽³⁾
	1	Mounting Flange (Ceramic)		10000908	-----
3	2	Gasket, Outer Tube	14329	12973	14799
4	1	Optional Tube Support	10922	21525	21525
5	1	Tube, Assembly, Outer - lower flux	-----	100664-x ⁽¹⁾	100665-x ⁽¹⁾
	1	Tube, Assembly, Outer - higher flux	10011702-x ⁽¹⁾	100072-x ⁽¹⁾	100088-x ⁽¹⁾
	1	Tube, Assembly, Outer - ceramic		10002522-x ⁽¹⁾	-----
6	1	Housing, Exhaust, CI, 3" NPSM (Met.)	3913	3907	3967
	1	Housing, Exhaust, CI, Rp3 (Met.)	3913-1	3907-1	3967-1
	1	Housing, Exhaust, CI, 3" NPSM (Cer.)	3913-2	3907-2	3967-2
	1	Housing, Exhaust, CI, Rp3 (Cer.)	3913-3	3907-3	3967-3
7	8	Screw, Lock, M12x50mm, Zinc Plated	10012042	21519	10002524
8	2	Gasket, Inner Tube	10012046	12996	14798
9	1	Combustor Assembly (350mm) (Met.)	10011083-1	100655-x ⁽²⁾	100660-x ⁽²⁾
	1	Combustor Assembly (500mm) (Met.)	10011083-2	100655-x ⁽²⁾	100660-x ⁽²⁾
	1	Combustor Assembly (350mm) (Cer.)		10004829	10009697
	1	Combustor Assembly (500mm) (Cer.)		10004830	10009698
10	1	Tube Assembly, Deflector (350mm)	10011832-1	100656-2	100659-1
	1	Tube Assembly Deflector (500mm)	10011832-2	100656-1	100659-2
	1	Tube Assembly, Deflector (350mm Cer.)		10004910-1	-----
	1	Tube Assembly Deflector (500mm Cer.)		10004910-2	-----
11	1	Nozzle (Spark)	10011071-1	7125-3	7125-3
	1	Nozzle (Spark/Flame Rod)	10011071-2	7125-4	7125-4
12	1	Tube, gas (350mm)	10011073-1	22436-2	22436-2
	1	Tube, Gas (500mm)	10011073-2	22436-1	22436-1
13	4	Screw, Cap, Hex, M8x50	15893	15893	15893
14	12	Washer, M8, Lock, Zinc Plated	15222	15222	15222
15	1	Block, Inlet, Air, N.P.T.	7001-1	7001-2	3973-5
	1	Block, Inlet, Air, BSP	7001-3	7001-4	3973-7
16	4	FTG, Tap, Pressure, RO .125	13445	13445	13445
17	1	Orifice, Plate, Air	14934-x	14934-x	14188-x
18	1	Body	10011081-1	7140-1	7141-1
19	1	Cover	10011079-1	7139-2	7139-2
20	4	Screw, Cap, Hex, M8x22, Zinc Plated	15886	15886	15886
21	1	Burner Nameplate, Platform 1000	20729	20729	20729
22	4	Screw, Drive, U, 2.0 .125" Long	18933	18933	18933
23	1	Spark Rod (350mm)	150000-1	100205-7	100205-8
	1	Spark Rod (500mm)	150000-16	100205-6	100205-9
24	2	Ring, O,Viton, 1.049" ID .0935	14777	14777	14777
25	1	Orifice, Plate, Gas	14191-x	14191-x	14191-x
26	1	Block, Inlet, Gas, N.P.T.	3974-4	3974-4	3974-2
	1	Block, Inlet, Gas, B.S.P.	3974-3	3974-3	3974-1
27	4	Screw, Hex, M8x45	15887	15887	15887
28	1	Screw, Cap, Hex, M6x25 Zinc Plated	20245	20245	20245
29	1	Washer, M6, Lock, Split, Zinc Plated	15625	15625	15625
30	1	Peepsight, 3/8", N.P.T., Steel	17003	17003	17003
31	2	Peepsight, 1/2", N.P.T., Steel	11737	11737	11737
32	1	Flame Rod, (350mm)	100670-7	100670-2	100670-3
	1	Flame Rod, (500mm)	100670-8	100670-1	100670-4
33	1	Reducer	10011075	22435	22435
34	1	Locknut	10011074	25030	25030
35	1	Inner Tube - Metallic	-----	100662-x	100663-x
	-	Inner Tube - 150mm ceramic sections	10011076	22338	22336
	-	Inner Tube - 200mm ceramic sections	10011077	22337	22335
36	1	End Section - Metallic	-----	100668	100669
	1	End Section - Ceramic	10011078	22339	22340
37	2	Screw, Cap, Hex, M4x.7, 10LG, S.S.	22498	22498	22498
38	2	Washer, M4, Lock, S.S.	22499	22499	22499
39	1	Spacer, (Ceramic Combustor)		10004915	10009700
40	2	Gasket, (Ceramic Combustor)		10004916	10009701
41	1	Bushing	18505	-----	-----

(1) Where x equals Burner Length (350mm or 500mm) + Effective Length (Table 5 Price List 325)

(2) Where x is a function of input level.

(3) Where x equals Mounting Flange length in Table 6 on Price List 325-1 in mm.

Illustrated Parts List (Continued)





Offered By:

Power Equipment Company
2011 Williamsburg Road
Richmond, Virginia 23231
Phone (804) 236-3800
Fax (804) 236-3882

www.peconet.com