

Eclipse ThermJet



Burners

Model TJ0200
Version 2

PARAMETER	BURNER VELOCITY	MODEL TJ0200
Maximum input Btu/hr (kW)	Medium & High Velocity	2,000,000 (586)
Minimum Input, on-ratio Btu/hr (kW)	Medium & High Velocity	200,000 (59)
Minimum Input, fixed air Btu/hr (kW)	Medium & High Velocity	40,000 (12)
Gas inlet pressure required "w.c. (mbar) • Fuel pressure at gas inlet (Tap "B" – see page 3)	High Velocity	Nat. Gas 9.3 (23.0) Propane 12.7 (32.0) Butane 13.4 (34.0)
	Medium Velocity	Nat. Gas 7.1 (18.0) Propane 8.5 (21.0) Butane 6.9 (17.0)
Air inlet pressure required "w.c. (mbar) • 15% excess air at maximum input (Tap "A" – see page 3)	High Velocity	Nat. Gas 12.3 (31.0) Propane 14.1 (35.0) Butane 14.1 (35.0)
	Medium Velocity	Nat. Gas 10.0 (25.0) Propane 11.0 (28.0) Butane 11.0 (28.0)
High Fire Flame Length Inches (mm) (measured from end of combustor)	High Velocity	Nat. Gas 27 (685) Propane 30 (760) Butane 30 (760)
	Medium Velocity	Nat. Gas 36 (915) Propane 32 (810) Butane 32 (810)
Maximum flame velocity ft/s (m/s) • 15% excess air, at maximum input	High Velocity	500 (152.4)
	Medium Velocity	250 (76.2)
Maximum combustion air temperature	300° F (149 °C) For higher temperatures, use TJPCA (Data 206)	
Flame detection	U.V. scanner available for all combustors. Flame Rod available for use with alloy or silicon carbide combustors only.	
Fuel	Natural Gas, Propane, Butane <i>For any other mixed gas, contact Eclipse for orifice sizing.</i>	

- All information is based on laboratory testing in neutral (0.0" w.c.) pressure chamber. Different chamber size and conditions may affect the data.
- All information is based on standard combustor design. Changes in the combustor will alter performance and pressures.
- All inputs based upon gross calorific values.
- Eclipse reserves the right to change the construction and/or configuration of our products at any time without being obliged to adjust earlier supplies accordingly.
- Plumbing of air and gas will affect accuracy of orifice readings. All information is based on generally acceptable air and gas piping practices.
- Do not install the burner with the gas inlet rotated 90° clockwise with respect to the air inlet if operating on natural gas using a flame rod.

Performance Graphs





Correction factor for medium velocity combustor is 1.20
On ratio: combustion air is adjusted to 3% O₂ at any given input.

Emissions from the burner are influenced by:


- fuel type
- combustion air temperature
- firing rate
- chamber conditions
- percent of excess air

For estimates of other emissions, contact Eclipse.




Dimensions & Specifications Millimeters (Inches)

Burner Housing





Tap Locations





Combustor

Exhaust outlet diameter : High Velocity : Ø85 (3.35)
Medium Velocity : Ø105 (4.13)





Alloy Tube (AISI 310)

Weight: 4.2 lb (1.9 kg)
Max Chamber Temp: 1,750°F (950°C)




Silicon Carbide Tube

Weight: 3.1 lb (1.5 kg)
Max Chamber Temp: 2,500°F (1370°C)



Refractory Block (w/330 SS wrapper)

Weight: 66 lb (30 kg)
Max Chamber Temp: 2,800°F (1538°C)



Down Firing Block
 Weight: 80 lb (36.3 kg)
 Max. Chamber Temp: 2800°F (1535°C)



Eclipse Combustion

Offered By:

Power Equipment Company
2011 Williamsburg Road
Richmond, VA 23231
Phone: 804-236-3800 Fax: 804-236-3882

www.peconet.com