

Eclipse EM102 Digital Manometer



Basic Key Functions

1. "Select" Key

- Press once within an option menu to scroll through options. See below for more details.

2. "Hold" / "Min Max" Key

- Press once to hold the measured value
- Press twice to display the minimum and maximum values since last request
- Press again to return to the held value
- Press ESC to return to measuring; values are reset

3. ESC / ⏻ Key

- Press key until the device beeps to turn it on or off
- Press once to return to the previous screen

4. Backlight Key ☼

- Press once for backlight
- Press twice for brighter backlight
- Press three times for no backlight

5. "OK" Key

- Press once to start self-calibration. Self-calibration is performed by disconnecting the two pressure inlets of the sensor, then pressing the "OK" key. AutoZERO will display momentarily and then return to measuring
- Press once to validate a selected option. See below for more details

Functions available from the main screen

1. Select Pressure units

- Press "select" once. Press "ok". Press "select" repeatedly to scroll through unit options. Press "ok" to validate selection. Press ESC to return to measuring.

2. Automatic shut-off

- Press "select" twice. Press "ok". Press "select" repeatedly to scroll through minute options. Press "ok" to validate selection. Press ESC to return to measuring.

3. Turn Beep off or on

- Press "select" three times. Press "ok". Press "select" to activate or deactivate. Press "ok" to validate selection. Press ESC (or Select) to return to measuring.

How to change the battery

1. Press tab down on battery cover at the back of the instrument and remove.

2. Remove old battery

3. Insert the new battery in accordance with proper polarity as illustrated inside the housing

4. Replace the battery cover.

- This device takes a 9V battery
- Handle used battery in accordance with local regulations.



Offered By:

Power Equipment Company
2011 Williamsburg Road
Richmond, Virginia 23231
Phone (804) 236-3800
Fax (804) 236-3882

www.peconet.com